

GOOSETAIL OUTFEED

FOR GOSLING™ CANNING SYSTEMS



Let the GooseTail Outfeed Table do the accumulation work for you during Gosling canning runs.

The GooseTail allows batches of cans to collect on the machine before unloading, giving single Gosling operators extra time for other packaging tasks.



SPACIOUS CAN CAPACITY

Accumulate up to 40 standard 211-body cans or additional slim and sleek body cans at a time to streamline your outfeed process.



TOOL-FREE FOLDING DESIGN

Fold the GooseTail up or down in under 2 minutes with quick-release pins: no tools required once installed. When not in use, the GooseTail stows vertically to keep your Gosling footprint compact.



ANY-CAN COMPATIBILITY

Use the GooseTail for any can size without the need for change parts. Cans flow smoothly from the Gosling to the GooseTail without operator assistance.



BUILT-IN DRAINAGE

Funnel residual rinse water back to the canning system or mobile cart with the attached drainage tray.



TECHNICAL SPECIFICATIONS

DIMENSIONS as installed:

- Length: 23.7 in (60.2 cm)
- Width: 13.9 in (35.3 cm)
- Height: 13.8 in (35.1 cm)

CAN CAPACITY:

- 211 body: 40 cans
- 204 body: 57 cans
- 202 body: 63 cans

CAN BODY COMPATIBILITY:

- All can sizes

MACHINE COMPATIBILITY:

- Gosling 2.0 canning systems
- Gosling 1.0 canning systems

INSTALLATION: Self-installed

AVAILABLE ONLINE

SHOP.WILDGOOSEFILLING.COM



LEARN
MORE

+1 720.406.7442 | Sales@WildGooseFilling.com
www.WildGooseFilling.com

Wild Goose Filling
633 CTC Blvd Ste 100
Louisville, CO 80027 USA

European Offices
Barcelona, Spain
Trento, Italy